



Thank you for purchasing Happy Trails products. Our products are proudly hand made in Boise Idaho, USA. If you have any questions or concerns about the installation of this product, please contact us directly at 1-800-444-8770 or e-mail installation@happy-trail.com.

Before you begin, place the bike on a hard level surface where you have room to work. Lay out the parts included in this kit and compare to the parts list of these instructions. If any parts or hardware are missing, contact us immediately at the number listed above.

Step 1, Disassembly:

Remove the seat and turn signals, taking care not to damage wires. Remove the tail rack bolts on the side. Remove upper passenger peg bracket bolts. Remove helmet lock.

Step 2, Installation:

Installation is the same for both sides.

Install the SL rack threading the M8x80 bolt through the frontmost mount on top, through the factory tail rack, into the frame. Follow this with a M8x55 bolt at the left foot peg bracket and a M8x65 at the right foot peg bracket.

Mount the turn signal tabs as shown below using a M8x65 with a nut and washer on the back side. Make sure they are even and level side to side.

Install the turn signals in their new locations. Use the nylon spacers to space out the nut on the back side.

Note:

When installing HT guards and racks, **leave all bolts loose until entire rack is fitted.** This allows the rack to move and take up differences in frame construction.

We also recommend that removable strength thread locking compound be used on all threaded connections.



Step 2. Installation (continued):

Once the rack has all the mounting points attached, go back and tighten up all your points.

Your turn signal wires may need to be lengthened to fit.

Hardware List:

Left and right SL
Bolt Kit
Instructions
Turn signal tabs



Bolt List:

- 2 M8x80 SHCS
- 1 M8x55 SHCS
- 3 M8x65 SHCS
- 2 8mm Nylock Nuts
- 2 5/16 Flat Washer
- 2 Nylon Spacers



Rev. 1
May 27, 2009
J4
HTP4-1-1B-20