

## Thank you for your order!

We are still finalizing our instructions for this kit, so these instructions are temporary. Thankfully, installation is extremely easy, and we we've got a tutorial video on our YouTube channel -HappyTrailsMoto - that you can easily visit by [scanning the QR code below](#)! If you run into any issues or have any questions, please contact us at [support@happy-trail.com](mailto:support@happy-trail.com)!

### Hardware Kit Contents:

4 - 8x40mm Flange head bolts



### Step 1:

Remove the foot pegs from both sides of your bike by removing the OEM bolts using a 12mm wrench or socket. These bolts will not be re-used.

### Step 2:

Line up your center stand so that the two holes on the upper mounting plates line up with the threaded holes from which you just removed the OEM bolts, place your foot peg over the center stand mount plate, and begin threading the provided 8x40mm flange head bolts into place. **We recommend the use of blue thread lock when installing these bolts.** Thread the bolts down hand tight, but **do not tighten completely.** Do this on both sides of the bike.

### Step 3:

With the bolts hand tightened, push up on the center stand as high as it will go and now fully tighten the foot peg bolts to **18ft/lbs**. It is necessary to lift the stand up to prevent the center stand from contacting the kick stand while not deployed. Ensure that each bolt is tightened down completely and that there isn't any excessive movement of either the stand or the foot pegs. Congratulations, you're finished! Time to ride!