



Thank you for purchasing Happy Trails products. Our products are proudly hand made in Boise Idaho, USA. If you have any questions or concerns about the installation of this product, please contact us directly at 1-208-377-8771 or e-mail support@happy-trail.com.

Before you begin, place the bike on a hard level surface where you have room to work. Lay out the parts included in this kit and compare to the parts list on the final page of these instructions. If any parts or hardware are missing, contact us immediately at the number or email listed above.

Step 1

While installing the Bigfoot sidestand extension, it is ideal to fully remove the stand from the motorcycle however as long as the bike is securely strapped down the installation can be completed with the stand still attached.

Place the Bigfoot Extension on the bottom of the sidestand as in Fig 1. Use the Bigfoot as a template to mark two holes by pressing a brightly colored marker through the holes in the stand extension to mark the appropriate hole locations.

Step 2

With the holes marked as in Fig 2, use an automatic center punch to dent the drill holes prior to drilling.

Use a 1/4" or 6mm drill bit to drill the holes in the bottom of the stand foot.

Step 3

When the holes are drilled, place the Bigfoot extension on the stand and bolt it into place.

Fig 1



Fig 2



Fig 3



Step 4

Bolt the Bigfoot into place using two M6x16T bolts and two M6 Nylock Nuts. Tighten the bolts to 7 ft/lbs.

Fig 4



Recommended Tools:
4mm Allen Wrench
10mm Box End Wrench

Hardware List:
Bigfoot Sidestand Extension

- 2 M616T bolts (flat head)
- 2 M6N nuts



Happy Trails Products

6/15/15
Rev. 4
JE